

Why can't I print to my local printer?

1. Restart your computer. Occasionally, your local printer will lose connection to your computer.
2. Shut down the printer. Wait 15 seconds. Turn the printer back on.
3. Make sure all cables from the printer to the computer are secure.