

Monitor/Tower Power Issues:

1. Check to make sure all power cords are plugged in.
2. Make sure all cords connecting the monitor to the tower are plugged in tight.
3. If all cords are plugged in tight and that does not fix the problem call the solution center at 4810.